



Fuel Test Kit Assembly Manual



This kit includes

1. 300 PSI Goodyear® Hose certified fire proof by MSHA --- With Brass Barb Assembled
2. Industrial Hose Barb (Qty. 2, 102-04-04)
3. Brass Male Branch Tee (3600-04-04-04)
4. Flat Face (No-Spill) Nipple (HTMN-04)
5. Flat Face (No-Spill) Coupler (HTMC-04)
6. Steel Beaded Hose Barb (4404-04-04)
7. Hex Pipe Cap (5406C-04)



Attach hose barbs(2) to tee(3). Use sealant tape (PTFE).



Attach flat face nipple (4) to the middle tee thread.



Attach flat face coupler (5) to the assembled hose barb.



Connect the flat faces by pushing them together.



This picture demonstrates how it should look now, when the flat faces are connected.



Turn the coupler's collar to lock it. After unlocked, retract the coupler's head to disconnect the union



Attach the steel beaded hose barb(6) and cap(7).



Insert the beaded hose barb into the hose about 2/3in, for clean storage.



This is what the kit looks like when installed in a car.

Your Quality Connection

For more information and pricing, call 614-863-6930

